

# Installation in practice



1. The Initial situation, a flat roof with bitumen roofing\*.



2. Clean roof with broom.



3. Position and unroll ND Drainage System.



4. Unroll next ND Drainage System.



5. Place the ND Drainage System right next to the previous one.



6. The filter geotextile has to overlap.



7. Cut out the roof outlets.



8. Install ND Edge Retaining Profiles.



9. Fill vegetation-free zones with gravel.



10. Empty bags of ND Substrate.



11. Divide the ND Substrate equally (5-8 cm).



12. Create vegetation-free zones around roof outlets.



13. Plant ND Plug Plants - Sedum (15 to 20 pieces per m<sup>2</sup>).



14. ...or lay down the ND Vegetation Blankets.



15. Impression of the green roof directly after construction.



16. Impression of the green roof a few months after construction.